

FACT SHEET THE DEKRA BATTERY TEST FOR ELECTRIC CARS

Electric vehicles (EV) are increasingly popular as the world pivots away from fossil fuels, and this transition means that used electric cars will be the preferred option for many. It is therefore imperative to accurately and easily evaluate their performance and value, which depends to a considerable degree on the remaining capacity of the battery. High-voltage battery tests have been time-consuming and lacking in the transparency and objectivity that fosters confidence—until now.

An electric car battery test from the electromobility specialists

The DEKRA battery test for electric cars is fast, reliable and neutral, elevating the existing standard for high-voltage battery assessments. As electromobility experts with many years of experience, we know that the State of Health (SoH), defined as the remaining capacity, of a used electric car's battery impacts the value and performance of the vehicle. Our webbased application battery test for electric cars provides an accurate picture of the battery's SoH, determined on the basis of a 15-minute analysis. Covering a large number of electric car models from different car manufacturers, you get neutral, independent battery test results that you can rely on when driving, buying and selling used electric cars.

High-voltage battery State of Health (SoH) in minutes

Our solution delivers what car dealerships, leasing companies and private customers need in order to buy, sell and operate used electric cars with ease and confidence:

- High-voltage battery SoH analysis completed in 15 minutes
- A simple, user-friendly process: connect accelerate – report
- Transparent, reliable test results independent of car brands
- Easy-to-read SoH report on remaining battery capacity



A first insight into our webbased application User-friendly and simple

1301 2000 ♥ 00.1945 ∞ Keine Internetwerblickung ▲ 192.168.4.1/diag_run	13.00 E B @ + ♥ ♥ 94%	12.59 ■ ● • • • • • • • • • • • • • • • • • •	12:57 € © Ø • ♥ 𝔅./ 94% ■ Ø Keine Internetivesbindung ● ▲ 192.168.4.1/diag_run ♥ ③ ⋮	12:56 ℃ @ @ • ※ <pre>% <pre< th=""></pre<></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre>
Cancel Stop	LANC (100) 1373 A (JAY (100) 1373 A USAW (100) 1373 A (071)	Apply data?		Image: Arrow of the second
Cancel Stop	Cancel Continue	First registration: Back Apply	First registration: Englisch Deutsch : X	
III O <	III D <	III O K	III O <	

The EV Battery Test: 4 simple steps



1. Preparation

Access the battery test URL from the smartphone and connect the Vehicle Communication Interface (VCI) to the cable and the cable to the On-Board Diagnostics (OBD) port of the vehicle.



2. Static test

Required diagnostic data is read out, allowing the software to verify the vehicle's general readiness.





3. Dynamic test

During a brief acceleration approximately 100 m —data is gathered so that the patented algorithm can perform its calculations.

4. DEKRA report

After the test is completed, the battery State of Health is displayed directly on the smartphone. The entire report can be send by email to user.



DEKRA Battery Tes for Elect	t ric Cars	DEKRA	DEKRA Battery Te for Ele
00884 SE / Youdweidendie 15 / 70565 Storger			DEKKA No. 53821/111111/2022.00000000.444
Mr John Smith 132, My Smeet, Bigtown BG23 4YZ England			Explanation of the
			Why do botheries spell
	95%	07027292 1430	Link Routes Insulation And advances indexes the top of each Not Routes indexes the top of each Not Routes index the deserved and an annual statistical deserved and an annual statistical deserved in a statistical deserved and the statistical deserved and the statistical deserved and an annual deserved in a statistical deserved and the Annual Annual Statistical deserved in a statistical deserved and the Annual Annual Annual Annual Annual Statistical Statistical deserved in a statistical deserved and the New York Deserved Routes I and the Annual Ann
Vehicle information:	OTM Data		New car the just be necessarily
Monufacturer.	SOC (Stote of Chorge)		Stating colours for soil or approximation for
Model / type:	SOH (Store of Health):		module 200 may be usin may to address
VIN:	Voltage:		mention was a manufacture of the second seco
Dicense plote:	Nominal capacity:		maketo of the Soft described related
first registration date:	Cell temperature min:		and and a sublem and an end of
Mleage / unit:	Cell temperature max:		requires to prifer along fait. No 100
	Cell voltage mirc		And Andrew Country and Andrew
	Cell vohge max:		
			CONTRACT IN A PROPERTY OF A PARTY

Battery Test for Electric Cars					
808 No. 33621/111111/2022 00000000.4444.6.6/0271330000005 87072022 1420					
Explanation of the results:					
Why do botheries age!	No conference when it the SDP is or one contents				
Unit Decembra biophase A salat decembra biophase (DE to generated on the much of Minutes biotect decembra the first recepting coulds. The Discourse constraints that or the order willing which the the decembra decembra and willing which the decembra decembra decembra and which the transmission of the much order or the single first recepting the suggest the recepting applications. Focusing the Silamatic quarky addressed (DE sizes)	and the coll-dation subject (see an exclusion). For a called to the basiney regardly and the ansatz of energy collects and theory for solid sets (see the collect of energy collects) and theory of the collect of the collect is find to experime the fitter of the energy solid sets of the exclusion for fitter of the energy solid sets of the energy solid sets of the exclusion of the exclusion fitter collect as requestions of energy the solid endergy solid sets of the exclusion of the exclusion endergy solid sets of the exclusion of the endergy endergy solid sets of the exclusion of the endergy solid endergy solid sets of the endergy solid sets of the endergy endergy solid sets of the endergy solid sets of the endergy solid endergy solid sets of the endergy solid sets of the endergy solid sets of the endergy solid sets of the endergy solid sets of the endergy solid sets of the endergy solid sets of the endergy solid sets of the endergy solid sets of the endergy solid sets				
add damps which more to be 20 upon upon how been	Unitations of all Fast Track Matheda:				
What does Soft (Sinte of Health) maan?	It is a right upper call expression is supported from the all signal fact work-calls care unit, determine force a fermal action incor the mathematical face and subsection works on unity				
This fully different different is used to describe the condition of a letters, if gives a conductor describer spling the fully a shear of the second second second second step. To determine the fully philotopy report is the shear step. To determine the fully philotopy report second last defininguit with a definant therburg one out and second second. The stepsize space is determined for conditions. It is second, the stepsize space is determined for the defininguit.	Birdy for charge d'ha companing agest of decir temperature licitings. For charges of solution agest and a digitigation for temperature of a solution agest agent. "Normal decirities a solution for the solution of the solution of the solution."				
second digends havely or fee distrings one in a disc work Adapted applicable on the diving good	Ange terpention of prints ange if he lattery				
Now can the Soll be measured?	New to charge your battery?				
The 2016 A 2014 stores for aging of the lattice, our for finders comparison of a regarded to so are function market. 2017 not fits and a regarded to be average approximation of a data part for barriers and the memory fits and data part of barriers comparing and to memory fits and and are part of the part of the memory fits and are part of the part of the fits memory fits and are part of the part of the part of the memory fits and are part of the part of the part of the memory fits and are part of the part of the part of the part of the memory fits and are part of the part of the part of the part of the part of the part of the part of the part of the part of the part of the part of the part of the part of the part of	Lond aport Alice of and concentration selection performance Research convolution legitic aport Alice Research Intelling interfaces and aport and a selection of the analysis of the patients of the aport of the aport Net and the approximation of the aport of the aport of the aport of the approximation of the aport of the aport of the aport of the aport of the optimized on a selection of the aport of the aport of the optimized of the aport of the aport of the aport of the aport of the optimized of the aport of the aport of the aport of the aport of the optimized of the aport of the aport of the aport of the aport of the optimized of the aport of the aport of the aport of the aport of the optimized of the aport of the aport of the aport of the aport of the optimized of the aport of the aport of the aport of the aport of the optimized of the aport of the aport of the aport of the aport of the optimized of the aport of the aport of the aport of the aport of the optimized				
1 famil α is defined destroyer one. Number where it is defined with the second state of the large state state of the large state state state is the large state state without the large state state state is the large state state state state state is the large state state state state is the large state state state state state is the large state					

An objective SoH report boosts transparency and confidence

The DEKRA report is intended to enhance confidence and trust between buyers, sellers and users of used electric cars. To this end, we have ensured that the document presents the essential information—first and foremost the battery's residual capacity—in easy-to-understand terms. Its validity is a function of our patented algorithm, which has been independently verified by the prestigious RWTH Aachen University. So far, a large range of car models can be tested, and we are continuously working to expand our database to include even more.

Why DEKRA?

Our **electric car battery test** is one of many solutions promoting safety and sustainability developed as part of our long-standing partnership with the automotive industry. Anticipating industry adaptations, we have intensified our activities and research in electromobility, maintaining our position at the forefront of automotive innovation. We continue to serve as a third-party service provider recognized for our expertise and committed to thinking forward for the good of our customers and for a safe, sustainable world.

Get in touch with our electromobility experts to learn more about our battery test for electric cars.



CONTACT US